


**TENSIL-1101 Reduction Adapters**

Cat no.	Socket size	Cone size
11 01 0001	10/19	14/23
11 01 0002	14/23	19/26
11 01 0003	14/23	24/29
11 01 0004	14/23	29/32
11 01 0005	19/26	24/29
11 01 0006	19/26	29/32
11 01 0007	19/26	34/35
11 01 0008	19/26	45/40
11 01 0009	19/26	55/44
11 01 0010	24/29	29/32
11 01 0011	24/29	34/35
11 01 0012	24/29	45/40
11 01 0013	24/29	55/44
11 01 0014	29/32	34/35
11 01 0015	29/32	45/40
11 01 0016	29/32	55/44
11 01 0017	34/35	45/40
11 01 0018	34/35	55/44
11 01 0019	45/40	55/44



TENSIL-1101

TENSIL-1102 Expansion Adapters

Cat no.	Socket size	Cone size
11 02 0001	14/23	10/19
11 02 0002	19/26	14/23
11 02 0003	24/29	19/26
11 02 0004	24/29	14/23
11 02 0005	29/32	24/29
11 02 0006	29/32	19/26
11 02 0007	29/32	14/23
11 02 0008	34/35	29/32
11 02 0009	34/35	24/29
11 02 0010	34/35	19/26
11 02 0011	34/35	14/23
11 02 0012	45/40	34/35
11 02 0013	45/40	29/32
11 02 0014	45/40	24/29
11 02 0015	55/44	45/40
11 02 0016	55/44	34/35



TENSIL-1102

TENSIL-1103 Adapter Connecting Straight (cone to cone)

Cat no.	Cone size	Cone size
11 03 0001	14/23	14/23
11 03 0002	19/26	19/26
11 03 0003	24/29	24/29
11 03 0004	29/32	29/32
11 03 0005	34/35	34/35



TENSIL-1103



ADAPTERS



TENSIL-1104

TENSIL-1104 Adapter Connecting Straight (socket to socket)

Cat no.	Socket size	Cone size
11 04 0001	14/23	14/23
11 04 0002	19/26	19/26
11 04 0003	24/29	24/29
11 04 0004	29/32	29/32
11 04 0005	34/35	34/35



TENSIL-1105

TENSIL-1105 Adapter Connecting Straight

Cat no.	Socket size	Cone size
11 05 0001	14/23	14/23
11 05 0002	19/26	19/26
11 05 0003	24/29	24/29
11 05 0004	29/32	29/32
11 05 0005	34/35	34/35




TENSIL-1106

TENSIL-1106 Adapter with Sintered Disc***

Cat no.	Socket size	Cone size
11 06 0001	24/29	14/23
11 06 0002	24/29	19/26
11 06 0003	24/29	24/29
11 06 0004	29/32	14/23
11 06 0005	29/32	19/26
11 06 0006	29/32	24/29

**please specify the grade of sintered disc required, default it is grade 2



TENSIL-1108

TENSIL-1108 Multiple Adapter Two Neck Parallel

Cat no.	Socket size	Socket size	flask cone size
11 08 0001	10/19	10/19	14/23
11 08 0002	14/23	14/23	14/23
11 08 0003	19/26	19/26	19/26
11 08 0004	24/29	24/29	24/29
11 08 0005	29/32	29/32	29/32

**TENSIL-1109 Multiple Adapters, Two Neck One Vertical & One Angle Neck**


Cat no.	Socket size	Cone size	Angle socket
11 09 0001	19/26	19/26	19/26
11 09 0002	24/29	19/26	19/26
11 09 0003	19/26	24/29	19/26



TENSIL-1109

TENSIL-1110 Multiple Adapters Three Necks, Two Parallel & One Angle Neck


Cat no.	Parallel Neck socket size	Angle Neck Socket	Flask cone size
11 10 0001	14/23	14/23	19/26
11 10 0002	19/26	14/23	24/29
11 10 0003	19/26	19/26	24/29
11 10 0004	19/26	29/32	29/32
11 10 0005	19/26	29/32	34/35
11 10 0006	19/26	29/32	55/44



TENSIL-1110

TENSIL-1111 Swan Neck Adapters with Screw GL14 thread tube

Cat no.	Socket size	Cone size
11 11 0001	14/23	14/23
11 11 0002	19/26	19/26
11 11 0003	24/29	24/29
11 11 0004	29/32	29/32



TENSIL-1111

TENSIL-1112 Receiver Adapter, Vertical with GL14 Thread

Cat no.	Socket size	Cone size
11 12 0001	14/23	14/23
11 12 0002	19/26	19/26
11 12 0003	24/29	24/29
11 12 0004	29/32	29/32



TENSIL-1112



ADAPTERS



TENSIL-1113

TENSIL-1113 Adapter Swan Type.

Cat no.	Socket size	Cone size
11 13 0001	14/23	14/23
11 13 0002	19/26	19/26
11 13 0003	24/29	24/29
11 13 0004	29/32	29/32
11 13 0005	34/35	34/35



TENSIL-1114

TENSIL-1114 Cone Adapters Right Angle Connection Plain

Cat no.	Cone size	Tube Dia(mm)
11 14 0001	14/23	8
11 14 0002	19/26	9/8
11 14 0003	24/29	9/8
11 14 0004	29/32	9
11 14 0005	34/35	9/10

**please specify the side tube size



TENSIL-1115

TENSIL-1115 Cone Adapters Straight Connection Plain

Cat no.	Cone size	Tube Dia(mm)
11 15 0001	10/19	8
11 15 0002	14/23	8
11 15 0003	19/26	9/8
11 15 0004	24/29	9/8
11 15 0005	29/32	9/10
11 15 0006	34/35	9/10

**please specify the side tube size



TENSIL-1116

TENSIL-1116 Cone Adapters Right Angle Connection with Glass Key Stopcock

Cat no.	Cone size	Tube Dia(mm)
11 16 0001	14/23	8
11 16 0002	19/26	8
11 16 0003	24/29	9
11 16 0004	29/32	9
11 16 0005	34/35	9

**please specify the side tube size

**TENSIL-1117 Cone Adapters Right Angle Connection with PTFE Stopcock**

Cat no.	Cone size	Bore (mm)	Side tube(mm)
11 17 0001	14/23	2mm	8
11 17 0002	19/26	2mm	8
11 17 0003	24/29	2mm	9
11 17 0004	29/32	4mm	9
11 17 0005	34/35	4mm	9

**please specify the side tube size



TENSIL-1117

TENSIL-1118 Cone Adapters Straight Connection with Glass Key Stopcock

Cat no.	Cone size	Side tube(mm)
11 18 0001	14/23	8
11 18 0002	19/26	8
11 18 0003	24/29	9
11 18 0004	29/32	9
11 18 0005	34/35	9

**please specify the side tube size



TENSIL-1118

TENSIL-1119 Cone Adapters Straight Connection with PTFE Stopcock

Cat no.	Cone size	Bore (mm)	Side tube(mm)
11 19 0001	14/23	2mm	8
11 19 0002	19/26	2mm	8
11 19 0003	24/29	2mm	9
11 19 0004	29/32	4mm	9
11 19 0005	34/35	4mm	9

**please specify the side tube size



TENSIL-1119

TENSIL-1120 Socket Adapters Straight Connection with PTFE Stopcock

Cat no.	Socket size	Bore (mm)	Side tube(mm)
11 20 0001	14/23	2mm	8
11 20 0002	19/23	2mm	8
11 20 0003	24/29	2mm	9
11 20 0004	29/32	4mm	9
11 20 0005	34/35	4mm	9


**please specify the side tube size



TENSIL-1120



ADAPTERS



TENSIL-1153

TENSIL-1153 Cone Adapter T Bore Glass Stopcock

Cat no.	Cone size	Bore (mm)	Side tube(mm)
11 53 0001	14/23	2	8
11 53 0002	19/26	2	8
11 53 0003	24/29	2	9
11 53 0004	29/32	2	9

**please specify the side tube size



TENSIL-1154

TENSIL-1154 Cone Adapter T Bore PTFE Stopcock

Cat no.	Cone size	Bore (mm)	Side tube(mm)
11 54 0001	14/23	2mm	8
11 54 0002	19/26	2mm	8
11 54 0003	24/29	2mm	9
11 54 0004	29/32	2mm	9

**please specify the side tube size




TENSIL-1155

TENSIL-1155 Cone Adapters Two Way Double Oblique Bore Glass Stopcock

Cat no.	Cone size	Bore (mm)	Side tube(mm)
11 55 0001	14/23	2mm	8
11 55 0002	19/26	2mm	8
11 55 0003	24/29	2mm	9
11 55 0004	29/32	2mm	9

**please specify the side tube size



TENSIL-1156

TENSIL-1156 Cone Adapters Two Way Double Oblique Bore PTFE Stopcock


Cat no.	Cone size	Bore (mm)	Side tube(mm)
11 56 0001	14/23	2mm	8
11 56 0002	19/26	2mm	8
11 56 0003	24/29	2mm	9
11 56 0004	29/32	2mm	9

**please specify the side tube size

**TENSIL-1121 Socket Adapters Right Angle Connection with PTFE Stopcock**

Cat no.	Socket size	Bore (mm)	Side tube(mm)
11 21 0001	14/23	2mm	8
11 21 0002	19/26	2mm	8
11 21 0003	24/29	2mm	9
11 21 0004	29/32	4mm	9
11 21 0005	34/35	4mm	9

**please specify the side tube size



TENSIL-1121

TENSIL-1122 Receiver Adapter Plain Bend Short

Cat no.	Socket size	Length (mm)
11 22 0001	14/23	75mm
11 22 0002	19/26	75mm
11 22 0003	24/29	100mm
11 22 0004	29/32	100mm
11 22 0005	34/35	100mm



TENSIL-1122

TENSIL-1123 Receiver Adapters Plain Bend Long

Cat no.	Socket size	Length (mm)
11 23 0001	10/19	100mm
11 23 0002	14/23	150mm
11 23 0003	19/26	150mm
11 23 0004	24/29	150mm
11 23 0005	29/32	200mm
11 23 0006	34/35	200mm



TENSIL-1123

TENSIL-1124 Receiver Adapters Straight Delivery

Cat no.	Socket size	Length (mm)
11 24 0001	10/19	75mm
11 24 0002	14/23	75mm
11 24 0003	19/26	75mm
11 24 0004	24/29	100mm
11 24 0005	29/32	150mm
11 24 0006	34/35	150mm



TENSIL-1124




ADAPTERS



TENSIL-1125

TENSIL-1125 Receiver Adapter, Plain Bend, Socket to cone.

Cat no.	Socket size	Cone size
11 25 0001	14/23	14/23
11 25 0002	19/26	19/26
11 25 0003	19/26	24/29
11 25 0004	24/29	24/29
11 25 0005	29/32	29/32
11 25 0006	34/35	34/35



TENSIL-1126

TENSIL-1126 Receiver Adapter, Plain Bent, with Vacuum tube.

Cat no.	Socket size	Cone size
11 26 0001	14/23	14/23
11 26 0002	19/26	19/26
11 26 0003	24/29	24/29
11 26 0004	24/29	19/26
11 26 0005	29/32	29/32
11 26 0006	29/32	34/35
11 26 0007	34/35	34/35

**please specify the side tube size



TENSIL-1128

TENSIL-1128 Receiver Adapter Bend with Vacuum Connection

Cat no.	Socket size	Cone size
11 28 0001	14/23	14/23
11 28 0002	14/23	19/26
11 28 0003	19/26	19/26
11 28 0004	19/26	24/29
11 28 0005	24/29	24/29
11 28 0006	24/29	29/32
11 28 0007	29/32	29/32
11 28 0008	29/32	34/35
11 28 0009	34/35	34/35

**please specify the side tube size



TENSIL-1129

TENSIL-1129 Receiver Adapter, Vertical with Vacuum Connection


Cat no.	Socket size	Cone size
11 29 0001	14/23	14/23
11 29 0002	14/23	19/26
11 29 0003	19/26	24/29
11 29 0004	24/29	24/29
11 29 0005	19/26	19/26
11 29 0006	29/32	29/32

**please specify the side tube size



TENSIL-1130 Receiver Adapter Bend Multi limb with Vacuum connection (without flask)

Cat no.	Socket size	Cone size x3
11 30 0001	14/23	14/23
11 30 0002	19/26	14/23
11 30 0003	24/29	19/26
11 30 0004	24/29	24/29



TENSIL-1130

(A) without Vacuum Connection (B) with Vacuum Connection

**Kindly Specify (A) or (B)

TENSIL-1131 Receiver Adapter with bend, flask & Vacuum connection.

Cat no.	Socket size	Cone size x4	Flask Cap. (ml)
11 31 0001	19/26	14/23	100ml
11 31 0002	24/29	19/26	125ml
11 31 0003	24/29	24/29	250ml



TENSIL-1131

TENSIL-1132 Receiver Adapter Multi-limb with Vacuum Connection

Cat no.	Socket size	Cone size x4
11 32 0001	19/26	14/23
11 32 0002	24/29	19/26
11 32 0003	24/29	24/29



TENSIL-1132

TENSIL-1133 Receiver Adapter Vertical Delivery (side ways)


Cat no.	Socket size	Cone size
11 33 0001	19/26	14/23
11 33 0002	24/29	19/26
11 33 0003	24/29	24/29



TENSIL-1133




ADAPTERS



TENSIL-1134

TENSIL-1134 Receiver Adapter Sloping Delivery


Cat no.	Socket size	Cone size
11 34 0001	19/26	14/23
11 34 0002	24/29	19/26
11 34 0003	24/29	24/29



TENSIL-1135

TENSIL-1135 Intermediate Receiver Adapter (Perkin Adapter) with High Performance Screwcock

Cat no.	Socket size	Cone size	Cap. (ml)
11 35 0001	14/23	14/23	10ml
11 35 0002	19/26	19/26	32ml
11 35 0003	19/26	24/29	32ml
11 35 0004	24/29	24/29	32ml
11 35 0005	29/32	29/32	50ml



TENSIL-1136

TENSIL-1136 Intermediate Receiver Adapter with Glass key High Vacuum Stopcock (Perkin Adapter)

Cat no.	Socket size	Cone size	Cap. (ml)
11 36 0001	14/23	14/23	10ml
11 36 0002	19/26	19/26	32ml
11 36 0003	19/26	24/29	32ml
11 36 0004	24/29	24/29	32ml



TENSIL-1137

TENSIL-1137 Recovery Bend, Sloping

Cat no.	Flask cone size	Cond. Cone size
11 37 0001	14/23	14/23
11 37 0002	19/26	19/26
11 37 0003	24/29	14/23
11 37 0004	24/29	19/26
11 37 0005	24/29	24/29
11 37 0006	29/32	19/26
11 37 0007	29/32	29/32
11 37 0008	34/35	19/26
11 37 0009	34/35	24/29
11 37 0010	34/35	34/35

**TENSIL-1138 Recovery Bend, Vertical**


Cat no.	Flask cone size	Cond. Cone size
11 38 0001	14/23	14/23
11 38 0002	19/26	19/26
11 38 0003	24/29	19/26
11 38 0004	24/29	24/29
11 38 0005	34/35	34/35



TENSIL-1138

TENSIL-1139 Plain Still Heads, Sloping


Cat no.	Flask cone size	Cond. Cone size	Socket size
11 39 0001	10/19	10/19	10/19
11 39 0002	14/23	14/23	14/23
11 39 0003	19/26	19/26	14/23
11 39 0004	19/26	19/26	19/26
11 39 0005	24/29	19/26	14/23
11 39 0006	24/29	24/29	14/23
11 39 0007	29/32	19/26	14/23
11 39 0008	29/32	29/32	14/23
11 39 0009	34/35	19/26	14/23
11 39 0010	34/35	24/29	14/23
11 39 0011	34/35	34/35	14/23



TENSIL-1139

TENSIL-1140 Plain Still Heads, Vertical


Cat no.	Flask cone size	Cond. Cone size	Socket size
11 40 0001	10/19	10/19	10/19
11 40 0002	14/23	14/23	14/23
11 40 0003	19/26	19/26	14/23
11 40 0004	24/29	19/26	14/23
11 40 0005	24/29	24/29	14/23
11 40 0006	29/32	19/26	14/23
11 40 0007	29/32	29/32	14/23
11 40 0008	34/35	19/26	14/23
11 40 0009	34/35	24/29	14/23
11 40 0010	34/35	34/35	14/23



TENSIL-1140

TENSIL-1141 Claisen Heads, Anti foaming sloping

Cat no.	Flask cone size	Cond. Cone size	Socket size
11 41 0001	14/23	14/23	14/23
11 41 0002	19/26	19/26	14/23
11 41 0003	24/29	19/26	14/23
11 41 0004	24/29	24/29	14/23
11 41 0005	29/32	29/32	14/23
11 41 0006	34/35	19/26	14/23



TENSIL-1141



ADAPTERS



TENSIL-1142

TENSIL-1142 Splash Head Adapters, Kjeldahl Trap


Cat no.	Socket size	Cone size
11 42 0001	19/26	24/29
11 42 0002	24/29	24/29
11 42 0003	24/29	19/26
11 42 0004	29/32	24/29
11 42 0005	29/32	19/26
11 42 0006	29/32	14/23



TENSIL-1143

TENSIL-1143 Splash Heads, Sloping


Cat no.	Socket size	Cone size
11 43 0001	14/23	14/23
11 43 0002	19/26	19/26
11 43 0003	24/29	14/23
11 43 0004	24/29	19/26
11 43 0005	24/29	24/29
11 43 0006	29/32	19/26
11 43 0007	29/32	24/29
11 43 0008	34/35	24/29



TENSIL-1145

TENSIL-1145 Splash Heads, Vertical

Cat no.	Socket size	Cone size
11 45 0001	19/26	19/26
11 45 0002	24/29	19/26
11 45 0003	24/29	24/29



TENSIL-1147

TENSIL-1147 Adapter with GL Threads

Cat no.	Socket size	Cone size
11 47 0001	14/23	GL14
11 47 0002	14/23	GL18
11 47 0003	19/26	GL14
11 47 0004	19/26	GL18
11 47 0005	19/26	GL25
11 47 0006	24/29	GL14
11 47 0007	24/29	GL18
11 47 0008	24/29	GL25
11 47 0009	29/32	GL14
11 47 0010	29/32	GL18
11 47 0011	29/32	GL25
11 47 0012	29/32	GL32

**TENSIL-1147 GL Thread Caps with aperture**

Cat No.	GL Threads
11 47 0021	14
11 47 0022	18
11 47 0023	25
11 47 0024	32
11 47 0025	45
11 47 0026	80



TENSIL-1147

TENSIL-1147 GL Thread Silicone Rubber Seals with aperture

Cat No.	GL Caps	OD x ID
11 47 0031	14	12x6
11 47 0032	18	16x6
11 47 0033	18	16x8
11 47 0034	18	16x10
11 47 0035	25	22x8
11 47 0036	25	22x10
11 47 0037	32	29x10
11 47 0038	32	29x12
11 47 0039	45	42x26



TENSIL-1147

TENSIL-1148 Adapter for Thermometers with Adjustable PTFE Cone (without Thermometer)

Cat no.	Cone size
11 48 0001	10/19
11 48 0002	14/23
11 48 0003	19/26
11 48 0004	24/29
11 48 0005	29/32
11 48 0006	34/35



TENSIL-1148

TENSIL-1149 Glass Adapter inner Threads with PTFE bush for Thermometer

Cat no.	Cone size
11 49 0001	14/23
11 49 0002	19/26
11 49 0003	24/29
11 49 0004	29/32
11 49 0005	34/35



TENSIL-1149



ADAPTERS



TENSIL-1150

TENSIL-1150 Thermometers Pocket, Closed End

Cat no.	Cone size	Flask Cap. (ml)
11 50 0001	10/19	10 ml
11 50 0002	14/23	25 ml
11 50 0003	14/23	50 ml
11 50 0004	19/26	100 ml
11 50 0005	19/26	250 ml
11 50 0006	24/29	500 ml
11 50 0007	24/29	1000 ml
11 50 0008	24/29	2000 ml
11 50 0009	24/29	3000 ml
11 50 0010	24/29	5000 ml
11 50 0011	29/32	10000 ml
11 50 0012	29/32	20000 ml

**kindly specify the flask size & neck size



TENSIL-1151

TENSIL-1151 Air/Steam Inlet Tubes, Bent

Cat no.	Cone size	Flask Cap. (ml)
11 51 0001	14/23	10 ml
11 51 0002	14/23	25 ml
11 51 0003	14/23	50 ml
11 51 0004	19/26	100 ml
11 51 0005	19/26	250 ml
11 51 0006	24/29	500 ml
11 51 0007	24/29	1000 ml
11 51 0008	24/29	2000 ml
11 51 0009	24/29	5000 ml
11 51 0010	24/29	10000 ml
11 51 0011	24/29	20000 ml

**kindly specify the flask & neck size

Tensil Labglass Welcomes enquiries

for the manufacture of special Custom designed Glassware,
whether for the laboratory or for the Industrial application,
our team of highly skilled and experienced Glassblowers,
Complimented by manufacturing equipment have experience
with borosilicate 3.3 expansion glass/borosilicate type I glass.